



Remove protective film from both sides of clear visor. Use one of the anti-fog/anti-static wipes to treat both sides of clear visor. Then follow these steps:

1- Slip left (square) cutout of visor, underneath left retaining tab and over it, then snapping it into place.

2- Align and snap center rectangular tab into center cutout in visor.

3- Slip right side cutout underneath and over right retaining tab, snapping it into place.

4- Attach elastic band, with tension adjusted for your comfort.